TECHNICAL INFORMATION

CITIZEN QUARTZ
Cal.No.916

**



§1. OUTLINE



This watch features the regular display of "hour", "minute", "second", "AM/PM", "day" and "date" plus "year" and "month" if necessary. The time display can be switched between the 12-hour and 24-hour periods.

In addition, such additional mechanisms are incorporated as the internal illumination lamp, power cell life indicating device, automatic calendar setting device and others.

§2. MAIN FEATURES

- 1. The time display is possible to switch between the 12-hour and 24-hour periods in accordance with the individual way of life of the watch customer.
- 2. The time screen displays various kinds of information including "hour", "minute", "second", "AM/PM", "day" and "date".
- 3. The colon on the time screen will start to flash when the power cell requires replacement.
- 4. The calendar can be set automatically including the leap year.
- 5. The internal illumination lamp facilitates an easy reading of the display information even in a dark place.


(916**)

§ 3. SPECIFICATIONS

Caliber No.		9160A	
Movement	Diameter	25.7 mmφ	
	Thickness	4.22 mm	
Oscillation		32,768Hz	
Accuracy		±10 sec./month under normal temperature	
Display syst	em	FE twist type nematic LC display	
Display information		12-hour period display: "Hour", "minute", "second", "AM/PM", "date" and "day"	
		24-hour period display: "Hour", "minute", "second", "date" and "day"	
		*The "year" and "month" are also displayed when the display is corrected.	
Correction of display		Independent correction for each digit through push-button operation	
Effective te	mperature range	0°C ~ +60°C (32°F ~ 140°F)	
Integrated of	circuit	C/MOS-LSI (1 unit)	
Additional	mechanisms	 Internal illumination lamp Power cell life indicating device (Flashing of colon) Automatic calendar setting at the end of each year and month 	
Power cell		Small-size silver oxide power cell (1 unit) Parts No.: 280–30 Nominal voltage: 1.55V Capacity: 38 mAH Size: 11.6 mm ϕ × 2.1 mm t Life: 1 year (5 sec. lighting/day)	

§ 4. HANDLING INSTRUCTIONS


1. How to read time and calendar



2. How to set time and calendar


•The switching between the 12-hour and 24-hour period displays is possible when the time or calendar is set.

After setting of the day, "12H" or "24H" as shown in figure below is displayed by pushing \$ button and changed over with every push of $\^{}$ button.



•The illumination lamp usually lights up with push of ① button but does not when setting the time and the calendar even with push of ① button.

The following setting procedure is based on the 12-hour period display.



§ 5. DISASSEMBLY AND ASSEMBLY OF MOVEMENT

Disassembling procedure: $\bigcirc \rightarrow \bigcirc$ Assembling procedure : $\bigcirc \rightarrow \bigcirc$

The number of screws necessary for parts is shown in the symbol like () 2).


The power cell must be assembled with the plus-side up.


Avoid washing the electronic parts. The dust and stains must be cleared away since they may impair good contact.

No lubrication is required for the movement.


Handling of power cell strap:

As shown in the diagram below, the power cell strap does not hold the power cell in the state completed with the appearance parts. When measuring the time rate with a single unit of the movement, turn the power cell strap as indicated in the diagram to fix the power cell.







To avoid giving scratches or stains to the surface of the LC display panel or the plate complete, handle them carefully.



§6. TROUBLESHOOTING AND ADJUSTMENT






Watch stop - No display at all

Measurement of power cell voltage

Power cell voltage: Over 1.5V



Result and Treatment

Over 1.5V

- No display of LC display panel
 Replacement of plate complete

Under 1.5V

Replacement of power cell:

- Correct display of LC display panel

 Measurement of power consumption
- No display of LC display panel
 Replacement of plate complete


Note:

If the watch has been used more than one year, replace the power cell with the new one even if it shows more than 1.5V output.

How to Put in Power Cell



The power cell must be put into the watch with the plus (+) side up.



^{*}In case the power cell itself shows more than 1.5V output and nevertheless the measured value is unsteady when the power cell is put into the watch, an incomplete contact is conceivable for the power cell. So the dust or stains sticked on the contact surface must be cleared away as well as the malformation of the contact surface must be corrected.

Big error recognized in time rate Check items How to check Results **Treatment** 2 Confirmation The big error of the time rate is corrected by of time rate turning the trimmer condenser. adjustment Time adjustment-➤ Common check possible items Time adjustment-➤ Replacement of impossible plate complete Trimmer CITIZEN WATCH CO condenser Gain 9160A In case the time adjustment is impossible with the trimmer condenser, the quartz crystal oscillator may have some fault. And the trimmer condenser may have some fault if the time rate

has no change at all.

Check items	How to check	Results	Treatment
Confirmation of using condition	How the watch has been used is confirmed to the customer. 1. Check whether the customer made any mistake in handling the watch. 2. Check whether the watch was used in an extreme temperature, i.e., outside the effective temperature range. 3. Other using factors.		
	Check point: In case the customer complains of the incorrect time for his watch although the instantaneous time rate is correct, the statistic data must be collected concerning the watch using condition.		
	This is an important must to know the relation between the incorrect time and the watch using condition.		i

Incomplete functioning of display mechanism — Partial segment break

Check items	How to check	Results	Treatment
Check of display panel contact areas	When the segment breaks partially, an incomplete contact is first considered between the LC display panel and the electronic circuit. And then some fault is conceivable within the electronic circuit.		
	Check of LC display panel holder and its screws (1) Check whether the screw is loose or	Screw broken	➤ Replacement
	broken. (2) Check whether the LC display panel	Screw loosened	➤ Retightening
	holder is holding evenly the LC display panel with no upward warp.	Uneven holding	➤ Reassembly
	Screw for LC display panel holder	Deformation of LC display panel holder	➤ Replacement
	 2. Check of LC display connection rubber (1) Check whether the connection rubber is twisted. (2) Check whether the rubber is worn out or extremely stretched. 	Rubber twistedor worn out	➤ Replacement
·	(3) Check whether any dust or stains stick to the rubber.	Dust or stains ————sticked	→ Clearing
	LC display connection rubber		
·	3. Check whether any dust or stains stick to the electrode part of the LC display panel or whether any breakage is recognized there. Also have a meticulous check for the electrode at the broken segment part.	Dust or stains ————————————————————————————————————	→ Clearing
	Electrode part	Electrode	Replacement of LC display panel
	Sur Silly		
	12:3828	lightly with a finger. Ar	oken segment is pushed nd if the broken segment nown that the contact is
	TO COLOR		strong push to the LC to prevent the glass


Check items	How to check	Results	Treatment
Check of switch mechanism	In case the selection and correction is impossible for the display digit with no lamp lighting, some fault is conceivable within the electronic circuit or in the mechanical constitution including the unsteady contact, malformation of the parts and others. In this connection, the following check is conducted.		
	1. The movement is first taken out of the watchcase. Then each switch actuating spring is pushed with the tweezers or the like in order to check whether the correct operation is possible or not.	Correct operation possible	Nothing wrong with movemen 3. Check of push-buttons
		Something wrong with operation correction plighting	→ 4. Check of switch actuating springs
	Selection of correcting	f digit	
	2. Check of lighting mechanism As illustrated below, apply Citizen Multi- Tester adaptor to both lamp terminals at- tached to the plate complete, and check whether the lamp lights up or not.		·
		Lamp lighting	→ 4. Check of switch actuing springs
		No lamp lighting	Replacement plate complet
	Power cel		
	Power cel		
	Power cel		

Check items	How to check	Results	Treatment
	 Check of push-buttons In case the movement has nothing wrong, the push-buttons may have some defect. Each push-button is taken out of the watchcase. (1) Check whether the push-button has some bend or not. (2) The dust or stains sticked to the push-buttons must be cleared away completely. Also the dust sticked to the watchcase after removal of the push-buttons must be cleared away. (3) The push-buttons are set to the watchcase to confirm a smooth operation of the buttons. (The silicon oil must be applied to the push-buttons of the push-buttons of the push-buttons. 	Button deformed or broken Dust or stains sticked	➤ Replacement ➤ Clearing
	Never fail to clear away the dust or stains sticked to the push-buttons at all times even when the troubleshooting is given to other parts of the watch.		
	 4. Check of switch actuating springs (1) Check whether the switch actuating spring (II) and (III) have some malformation or breakage. (2) Check whether the contact parts of switch actuating spring (II) and (III) have correct contact with the pattern of the plate complete. In this case, a meticulous inspection must be given to the dust or stains sticked to the contact part as well. 		Replacement of reassembly Replacement of plate complete
	Switch actuating spring (III) Switch actuating spring (IIII)		

Common check items

6 Measurement of power cell voltage

Power cell voltage: Over 1.5V



Result and Treatment

Over 1.5V

Measurement of power consumption

Under 1.5V

Replacement of power cell:

Measurement of power consumption

Note

If the watch has been used more than one year, replace the power cell with the new one even if it shows more than 1.5V output.


How to Put in Power Cell

The power cell must be put into the watch with the plus (+) side up.

^{*}In case the power cell itself shows more than 1.5V output and nevertheless the measured value is unsteady when the power cell is put into the watch, an incomplete contact is conceivable for the power cell. So the dust or stains sticked to the contact surface must be cleared away as well as the malformation of the contact surface must be corrected.

Measurement of power consumption

Power consumption: Under $4.0\mu A$



Result and Treatment

1. Measurement under normal condition:

Under 4.0µA

→ 8 Time adjustment

Over 4.0µA

- ➤ 2. Measurement of power consumption of electronic circuit part
- Measurement of power consumption of electronic circuit part with LC display panel removed:

Under 2.0µA

 Replacement of LC display panel connection rubber or LC display panel

In this case, an inspection must be given to the dust or stains sticked.

Over 2.0µA

➤ Replacement of plate complete

Note

A power cell of more than 1.5V output must be installed into the power cell holder of the adaptor.

Check items	How to check	Results	Treatment
7 Time adjust- ment	The time rate is measured using a timing machine, and then the time is adjusted.		
	CITIZEN WATCH CO SO 0 JEMIS UMAUJISTO GAIN GAIN		
	The time rate is adjusted by turning the screw of the trimmer condenser.		

	Check items	How to check	Results	Treatment
•	Check of appearance functions	Finally, the following points are confirmed. 1. The figures displayed must be correct. 2. Each operation must be performed in a correct way. 3. No dust nor stains stick to the appearance parts.		
		COTIZEN LO:3828 STINIS LO Q		
- 1				

CITIZEN WATCH CO., LTD. Tokyo, Japan