



Pignon de remontoir
 Winding pinion
 Piñón de remontuar (rueda de canto)
 Aufzugtrieb (Transmissionsrad)
 Rocchetto di carica

3 AC

3 AH

4 AR

4 AU

4 AX

5 A

5 AD

5 AH

5 AN

5 AR

5 AB

5 AC

5 AF

6 A

6 C

6 AH

6 AK

6 AM

6 AZ

6 BA

6 BC

6 BD

6 BE

6 BK

6 BKC

6 BL

6 BM

6 BMC

6 BO

6 BOC

6 BS

6 CA

6 CAC

6 CE

6 BP

6 BPA

6 CHAC

6 COAC

6 CB

6 CBC

6 CF

6 CFC

6 EA

6 EB

7 AA

7 AH

★ 7 AK

7 AN

7 AP

7 AD

7 AF

7 AL

7 AM

7 BS

7 BSC

7 BU

7 BUC

7 BEAC

8 AC

8 AE

8 AD

8 AH

8 BA

8 BBA

9 AR

△ 9 ARC

9 AS

9 ASC

10 AK

10 AKcs

10 AKCH

★ 10 BH

10 BK

10 BM

10 BMC

10 BMCD

10 BC

10 BCC

10 BT

10 BTC

10 BU

10 BUC

10 BNCH

10 BOAC

10 BP

10 BPAC

10 BPAD

10 CB

10 CBAC

10 CBC

10 CBCD

10 CNCH

10 BRC

△ 10 CMC

10 CSC

10 BS

10 BZ

▽ 10 BZAC

10 BZACD

10 BZC

11 AB

11 ABC

11 AC

11 ACA

11 ACAC

11 ACC

11 AERC

11 AF

11 AFA

11 AFAC

▽ 11 AFACD

11 AFC

11 AFCD

11 AFD

11 AFF

17 AH

17 AHS

17 AL

17 ALS