




YM87A DISASSEMBLE CHART (1)



YM87A DISASSEMBLE CHART ②




YM87A DISASSEMBLE CHART (3)



Pin for train wheel bridge
夾板拖柱仔

Train wheel bridge
夾板



Center wheel for timer
時間中心輪

First intermediate wheel for timer
第一時間過輪

Second intermediate wheel for timer
第二時間過輪

Fourth wheel & pinion
4號輪

Small second wheel & pinion
小秒針輪

Fifth wheel & pinion 5號輪

Third wheel & pinion 3號輪

Minute wheel
分輪/度數輪

Intermediate wheel for alarm
響鬧過輪

Alarm center wheel
響鬧中心輪

Minute wheel for alarm
響鬧分輪

Intermediate wheel for mode
機能過輪

Mode wheel 機能中心輪

Switch lever (A)
控制竿 (A)

Setting lever 抑制竿

Yoke 橫擔

Train wheel setting lever
輪組止動竿

Switch lever (B)
控制竿 (B)

Setting wheel 撥針輪

Clutch wheel 豬籠輪

Setting stem
柄軸/把芯

YM87A DISASSEMBLE CHART (4)

