



AS01,AS06 Disassemble Chart (1)



- 1.Solar cell unit
太陽電池組件
4020 590 (φ 2080)
4020 594 (φ 2980)




- 2.Solar cell lead terminal
太陽電池引極
4246 533



- 3.Hour wheel plate
時輪掩 0376 507



- 4.Hour wheel
時輪 0271 764



AS01,AS06 Disassemble Chart (2)

