## TECHNICAL INFORMATION

# CITIZEN QUARTZ Cal. No. 6820





### **Fitting Procedure of Hands**

Step	Explanatory illustration	Remarks
Perform all reset.	VD	Electrically connect position (+) side of power cell (VDD) to (R) pattern form more than 2 seconds.  D R
2 Set module to "0" position confirmation mode.	Setting ster	If it is moving, push the switch stem four times, then confirm the mode wheel mark again.  * After setting, do not push the switch stem until the mode hand has been fitte
	Mark Insperwinds	ection

Step	Explanatory illustration	Remarks
Assemble parts     related to hour     wheel.		Assemble the hour wheel and dial washer.
1 Install the dial.		
f Install the second hand.		Install the second hand to any second division.
Confirm the 0 mode. "0" position confirmation mode	Switch stem	With switch stem at the normal position, push any one of (A), (B), and (C) button to confirm the demonstrative movement of the second hand.  * If the second hand does not demonstrate: a) Push the switch stem one time. b) Push any one of (A), (B), and (C) buttons.  b) Repeat a) and b) above until the second hand demonstrates at b).
Install the mode hand.	· · ·	Install the mode hand to the center of print of ▶ 0 ◀
3 Install the hour and minute hands.		Install the hour and minute hands to any hour and minute divisions since they will move independently.

Step	Explanatory illustration	Remarks
Install the module to the case.		Assemble the hour wheel and dial washer.
Perform "0-position setting".	B OFFER AND	<ol> <li>Pull the M button to first click.</li> <li>Push the A button to set the second hand to 0 second position (top of the dial), and the B button to set the hour hand to 0 hour position (top of the dial), and the button to set the minute hand to 0 minute position (top of the dial).</li> <li>Securely return the M button to the normal position.</li> </ol>
Set the watch to the present calendar and time.		

- -

### **Power cell Replacement Procedure**

When replacing the power cell, by sure to measure the power consumption of the watch, without taking the module out of the case.

### I. Measurement of current consumption

Step	Explanatory illustration	Remarks
Set the watch to the time mode.	City The Cop of a	
2 Set the tester for measuring current consumption, and apply the lead bars of the tester to ⊕ and ⊖ of the module.		Keep the lead bars applied until the measurement is finished.  ⊕: Power cell strap  ⊖: Power cell connector spring
3 Perform all reset.	⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕	Keep the lead bars applied, securely short the R terminal to power cell strap with pincers, etc. for more than 2 seconds.
Measure the current consumption.	* If there is any dirt or dust on any connecting part of the train wheel or circuit, the current consumption may be increased. Note this when measuring.	Read the current when the tester pointer is stabilized.  2.0 μA max. → OK
Operation after power cell replace- ment.	After the power cell is replaced, the information in the IC in the watch is wrong. Perform the "0-positon setting" to make each function work correctly. (See 6 to 6 on following pages.)	

### II.0-position setting

Step	Explanatory illustration	Remarks
Set the watch to the 0-position confirmation mode.	THE ORY	
Pull the (w) button to the first click.	B OFFE ON M	<ul> <li>a) Pull the  button to the first click.</li> <li>b) Push and keep the  B, B, and  buttons at the same time for more than 2 seconds.</li> <li>c) If the  B, B, and  buttons are released, a peeping alarm sound comes and the second, hour, and minute hands move a little. After the above operation is confirmed, perform the "0-position setting".</li> <li>d) Push the  button to set the second hand to 0 second position (top of the dial), and the  button to set the hour hand to 0 hour position (top of the dial), and the  button to set the minute hand to 0 minute position (top of the dial).</li> <li>e) Securely return the  button to the normal position.</li> </ul>
	M)	

Step	Explanatory illustration	Remarks
3 Set the watch to the time mode.	CHA A ARIST	
Set the watch to the present time.		a) Pull the  button to the first click.  *The hour hand indicates the hour in 24-hour system.  1 o'clock position → AM 2 o'clock position  6 o'clock position → PM 12 o'clock position  12 o'clock position  b) Push the  button to return the second hand to 0.  *When the  button is pushed, the minute hand moves as follows according to the position of the second hand.  0 - 29 seconds: Minute hand does not advance.  20 - 59 seconds: Minute hand moves by 1 minute.  c) The hour hand can be corrected with the  button.  d) The minute hand can be corrected with the  button.  e) Securely return the  button to the normal position.


marks
I Year hand Month hand Date hand
he M button to the
he year hand with atton. Calculate my years after the year, and set the the result.
ap years list on the year year after a leap nd year after a leap year after a leap
the month hand  B button.  position: January  position: February
k position: December the date hand withoutton.  by return the W
to the normal


- -

### **DISASSEMBLY AND ASSEMBLY OF THE MODULE**


### • Lubrication narjubgs

(a) ∴ A-Lube oil(b) ∴ V-Lube oil(c) ∴ CH-1 oil(d) ∴ F-Lube oil






# INSPECTION AND ADJUSTMENT METHOD OF MODULE



,



Check item	Method	Results and procedure
Check of connection parts	*Refer to the analog part of Technical Manual, Basic Course II-2-a.  If the output signal cannot be obtained for checking, dust	● Dust and dirt → Remove
	may be caught between electronic circuit unit and each part.	
	When the fixing screws of the electronic circuit unit are loosened, the output signal may not be obtained. Tighten those screws securely.	
Measurement of coil resistance	* Refer to Technical Manual, Basic Course II-1-c for the setting procedure of the tester.	
	<tester 10ω="" range:="" x=""></tester>	Resistance • Coil unit (1) 2.1 $k\Omega \sim 2.5 k\Omega$ $\rightarrow OK$ • Coil unit (2) 1.2 $k\Omega \sim 1.5 k\Omega$ $\rightarrow OK$
Check of train	* Pefer to Technical Manual Pegia Course H.O.h.	● If the train wheel is normal,
wheel	<ul> <li>* Refer to Technical Manual, Basic Course II-2-b.</li> <li>Confirm each part of the plastic gears are not be bent or broken.</li> </ul>	replace the electronic circuit unit.
6 Check of dial side	* Refer to Technical Manual, Basic Course II-2-c.	
	Each part of the plastic gears and pinions must not be bent or broken.	

Check item	Method	Results and procedure
*Set the watch to either alarm 1 or 2 mode.	*Refer to Technical Manual, Basic Course II-1-c for the setting procedure of the tester  *Tester range: DC 3V>  *(Measuring method)  Set the watch to either alarm 1 or 2 mode and set the alarm monitor, then apply the ⊕ lead bar of the tester to the top of the battery and the ⊖ one to the buzzer contact spring.  •If the part of the piezo-electric element stuck directly to the case back to which the buzzer contact spring will touch is cracked or broken, the alarm does not sound normally.  •Check the buzzer contact spring for deformation and fatigue.	<ul> <li>Tester pointer swings → OK</li> <li>Tester pointer does not swing at all → Replace the electronic circuit unit.</li> </ul>
Measurement of time rate  * Set the watch to the time mode.	*Refer to Technical Manual, Basic Course II-2-d.  Measure the time with CITIZEN QUARTZ TESTER.  • Measurement of time rate The time can be measured with the tester in any range.  Do not measure the time rate under the direct sunlight or incandescent lamp. If measured under them, the time rate may shift and may not be measured correctly.	

Check item	Method	Results and procedure
9 Check of using condition	<ul> <li>* Refer to Technical Manual, Basic Course II-2-e.</li> <li>• Since the accuracy may be affected by the environment of the watch, confirm the using condition of the watch (Magnetism, extremely high or low temperature and humidity, impacts, etc).</li> <li>• Confirm how many days have passed after the time was set last time.</li> </ul>	
Measurement of current consumption	*Refer to Technical Manual, Basic Course II-1-f for the setting procedure of the tester.	
* If there is any dirt or dust on any connecting part of the train wheel or circuit, the current consumption may be increased.	<tester 12μa="" dc="" range:="">  Power cell</tester>	<ul> <li>Under 2.0 μA         → OK</li> <li>Over 2.0 μA → Replace the electronic circuit unit.</li> </ul>
	(Measuring method) Refer to the measurement of current consumption in Battery replacement procedure I.	
1 Check of appearance and functions	* Refer to Technical Manual, Basic Course II-2-f.  Confirm there is not duct, dirt, etc. on the dial.  Confirm each push button works securely.	