## TECHNICAL INFORMATION

CITIZEN QUARTZ
Cal.No.890%%



#### §1. OUTLINE



This unique watch combines the advantages of a digital quartz watch and an analog quartz watch together. It is finished in a well unified design thanks to adoption of an L-shaped LC display panel completed through special processing, furthermore featuring a stopwatch function.

#### §2. FEATURES

- 1) A compact and multi-function watch for gentlemen's use.
  - a) One chip of C/MOS-LSI controls both the digital and analog functions.
  - b) The module size is as follows: Outer diameter 30.0mm $\phi$  (max.); Thickness 4.50mm (without power cell); Thickness with power cell 5.51mm.
- 2) A high accuracy can be maintained about three years with only one unit of small-size silver oxide power cell.
  - a) Accuracy at the normal temperature: ±15 sec. per month
  - b) Power cell No.: 280-15; Nominal power cell life: about 3 years
- 3) Digital display function
  - a) Time display (24-hour, minute & second) ←→ calendar display (month, date & day), plus stopwatch display
  - b) Automatic calendar setting at the end of each month and year (including the leap year)
  - c) Power cell life indicating device (with blinking of service mark, (The colon and the time or calendar mark start flashing).
- 4) Analog display function
  - a) 2 hands (4-second step movement for hour and minute hands)
  - b) Power conservation switch (to be actuated with pull-out of crown)
- 5) An easy time adjustment is possible by means of the trimmer condenser.
- 6) High-contrast and long-life FE-type LC display. With application of a special-form LC display panel, an easy-to-see display screen is obtained with increased functional efficiency.




## § 3. SPECIFICATIONS

Caliber No.	8900-08A		
Туре	Quartz crystal watch with digital-analog simultaneous display		
Movement	Size: $30.00$ mm $\phi$ Thickness: 4.50mm (5.51mm with power cell)		
Accuracy	±15 sec./month (at normal temperatures)		
Oscillation	32,768Hz		
Digital watch (Display system)	<ul> <li>FE twist type nematic LC display</li> <li>6-digit time display (hour, minute &amp; second)</li> <li>Calendar display by switching (month, date, day &amp; year)</li> <li>"Year" displayed only at display correction time</li> <li>Stopwatch function by selecting button</li> </ul>		
Analog watch (Display system)	•Time display (hour & minute) by two hands in 4-second step movement		
(Converter)	Bipolar step motor		
Effective temperature range	0°C ~ +60°C (32°F ~ 140°F)		
Integrated circuit	C/MOS-LSI (1 unit)		
Additional mechanisms	Automatic calendar setting at the end of each month and year (Digital)  Power cell life indicating device (Digital)  Power conservation switch (Analog)		
Power cell	Small-size silver oxide power cell (1 unit)  Parts No. : 280–15  Voltage : 1.5V  Capacity : 75mAH  Size : 11.6mmφ × 3.00mm  Life : About 3 years		

#### 4. HANDLING INSTRUCTION


## 1) Digital watch



### 2) Analog watch

- a) The crown is pulled out by one step and turned right or left to set the "hour" and "minute".
- b) The crown is pushed in to the original place to start the hands.
  - \*The power conservation state is also secured with pull-out of the crown.
  - \*The operation of the crown does not affect the digitial display mechanism at all.
- c) The hands move once per 4 seconds.

#### § 5. TIME AND CALENDAR SETTING




In case of only the "month", for example, is set, the (S) button is pushed four times. Then the "month" begins to blink and can be set with push of (R) button in the necessary pushing frequency. After setting the "month", the (ST) button is pushed

to secure the normal time display.

If (R) button pressed when indicating 30 to 59, then minutes will advance one minute.

last two digits of the year.

## § 6. STOPWATCH OPERATION



#### (1) Reset

The service mark "TIME" disappears, and " \* \* " ", "STOP.W" and "1/100" are displayed instead. The "hour", "minute" and "second" of the normal time display are charged to the "minute", "second" and "1/100" of the stopwatch display respectively. Here, "00min. 00sec. 00" is secured for the stopwatch timing.

## (2) Under operation

With push of (51) button under the reset state, the service mark " " begins to blink to indicate that the timing is being carried out.

## 3 Stop

With push of button under the operation state, the service mark " " " stops blinking. At the same time, the timing is also stopped and the elapsed time is displayed. If button is pushed under these conditions, the cumulative time can be displayed.

## 4 Lap (operation)

With push of  $\bigcirc{\mathbb{R}}$  button under operation, "LAP" is displayed along with the elapsed time. In this case the time measurement is continued. With push of  $\bigcirc{\mathbb{R}}$  button again, the continued time is displayed.

## (5) Lap (stop)


With push of (ST) button after pushing (R) button under operation, the timing is stopped under the "LAP" state. At this moment, the service mark "" stop blinking to indicate the stoppage of the timing. If (R) button is pushed under these conditions, the "LAP" display is erased and the "stop" state is secured.

## 6 Reset

With push of (R) button under the state of (3) shown in the above diagram, the zero-second reset is given with '00 00 00'' displayed. Thus, the "reset" state is secured.


## § 7. DISASSEMBLY AND ASSEMBLY OF MOVEMENT

### 1) Digital watch



## 2) Analog watch (I)


Lubrication mark:
Synt-A-Lube oil ®>
Synt-V-Lube oil ®>



## 3) Analog watch (II)


Note:

Avoid lubricating the center wheel and pinion.



## 4) Notabilia of disassembly and assembly


## (1) Connecting spring for display frame




As shown in the left diagram, the connecting spring for display frame is incorporated above the LC display panel holder. It functions to give a contact to the display frame and to prevent the electrostatic "noise" from giving an evil effect to the display.

In this connection, the connecting spring must be incorporated assuredly and correctly. When the spring performance is lost, the spring must be bent upward to secure an assured contact.

#### (2) Assembly of LC display panel supporter



The LC display panel supporter must be set in such a way that the unlocking lever for setting stem is put into the guide hole (with arrow and PUSH marks) of the LC display panel supporter.



- 1) The bent portion is put downward when incorporated.
- 2) When removing, the casing clamp is slided inward while being pushed down to be detached through the groove of the caseback.


## (4) Assembly of coil terminal connector


The coil terminal connector must be attached in such a way that the bent portion of the connector comes toward the coil terminal connector sheet.

#### (5) Assembly of power cell holder


The power cell holder can be fitted firmly to the pin of the device cover and thus must be pushed in until it is settled completely to the device cover.

## §8. TROUBLESHOOTING AND ADJUSTMENT





Measurement of power cell voltage



**Results and Treatment** 


Over 1.5V

→ Nothing wrong

Under 1.5V

Replacement of power cell

Check of unit of electronic circuit



The output signal is confirmed with the unit of electronic circuit in corporated.

#### **Results and Treatment**


There is nothing wrong as long as the tester pointer goes and comes back every 4 seconds.

In case the pointer swings out or other abnormality is recognized.

Replacement of unit of electronic circuit.


Check items	How to check	Results	Treatment
Check of LC display panel contact areas	An unsteady contact between the LC display panel and the electrode part as well as the faulty LC display panel are conceivable.		
	<ol> <li>The tightening condition is checked for the screws of LC display panel holder.</li> </ol>	Screw broken	➤ Replacement
		Uneven holding of panel	➤ Reassembly
	How the LC display panel contact rubber is incorporated is confirmed.	Rubber twisted or worn out	➤ Replacement
		Dust or stains ————————————————————————————————————	➤ Clearing
	3. The dust or stains sticked to the electrode part of the LC display panel are inspected as well as the crack of the LC display panel.	Panel cracked	→ Replacement
	Check point: The segment-broken area is pushed softly with a finger. If the broken segment is displayed again, it is known that the contact is unsteady.		
4 Check of	Check whether a good contact is secured be-		
contact part	tween the coil terminal connector sheet pro- truded over the unit of electronic circuit and the analog part.		
		Screw loosened	→ Retightening
	oil terminal connector	Unit of electronic circuit	
	Screw for coil terminal connector		
	*The coil terminal connector is attached in such a way that the curved area comes toward the coil terminal connector sheet.		
		1	





. (	Check items	How to check	Results	Treatment
6	Check of train wheels	Check whether each gear wheel has some creaking and dust or other foreign substances sticked.  *The rotor may have rotations if the hands are turned in a completed state of the analog movement. This is, however, just a matter of the designing and has nothing to do with the trouble.  Check of oiling condition	Crealing recognized  Dust and others sticked	➤ Replacement  ➤ Clearing
7	Check of dial side	Check of each transmission      *The train wheels have also rotations due to a designing although the center wheel and pinion itself should have a slip originally. The hand turning torque can be confirmed by removing the coil unit.		

Measurement of power consumption



#### **Results and Treatment**

Measurement under normal conditions.

#### Under 4.0µA

Nothing wrong

### Over 4.0µA

 Measurement of power consumption of electronic circuit.

#### Reference value

- 1 Unit of electronic circuit: About 1.5µA
- ② Converter (analog): About 1.0μA
- ③ LC display panel: About 1.0μA

Measurement of power
Consumption of electronic
circuit

## Under 2.0µA

→ Replacement of LC display panel connector or LC display panel

#### Over 2.0µA

Replacement of plate complete.

\*It is important to know what kind of component part has a large amount of power consumption in case a large power consumption is shown through the measurement.

Check items	How to check	Results	Treatment
Time adjustment	The time is adjusted by turning the trimmer condenser in case a big error is recognized in the time rate.	Time adjustment possible	Next item 10
		Time adjustment ————————————————————————————————————	Replacement of unit of electronic circuit
	Trimmer condenser Quartz crystal oscillator		
	EIGHT & JEWELS CITIZEN WATCH CO UNAQJUSTED JAPAN O Power cell		
	Set up to digital display  This watch can measure both out put of digital and analog. But analog movement moves once per four seconds. Therefore, it is better way that adjustment by digital display.		
Check of appearance functions	Check whether the time setting and the opera- tion of the power conservation switch are smooth and accurate with the crown pulled out.		
	Check whether each push-button can be operated in a smooth and correct way.		
	<ul> <li>Check whether the figures displayed have something wrong and whether some dust o stains stick to the appearance parts.</li> </ul>		
	,		

# CITIZEN WATCH CO., LTD. Tokyo, Japan